




TECHNICIAN'S TIP OF THE MONTH

We continue to experience a lot of issues due to preps not being rounded or tapered for anterior and posterior all-ceramic restorations. You should prepare a circular shoulder with rounded inner edges or a chamfer at an angle of approximately 10 to 30 degrees. Ensure the width of the circular shoulder/chamfer is at least 1.0 mm. See illustrations below for reduction guidelines.

Anterior



Posterior

