



Over-Denture Bar Flow Chart

First Appointment:

- * Take alginate impression.
- * Rx Requesting custom tray. (two days in Lab.)

Second Appointment:

- * Remove healing abutments. Tools can be rented if needed.
- * Place Impression copings. Tighten screw finger tight.
- * Take open tray impression for master cast.
- * Replace healing abutments.
- * Rx requesting Base plate and Wax Rims. (three days in Lab.)

Third Appointment:

- * Remove healing abutments.
- * Take Bite registration.
- * Put verification jig in place and lute together.
- * Replace healing abutments.
- * Rx requesting Bar and set-up. (fourteen days in Lab.)

Fourth Appointment:

- * Try-in Bar for passive fit.
- * Verify Set-up.
- * Return for process. (two days in Lab.)

Fifth Appointment:

- * Seat Bar and torque to proper specifications. Tools can be rented if needed.
- * Insert Denture.