



## Locator flow chart: New Denture

### First Appointment:

- \* Remove healing abutment – Measure depth of tissue, From the top of the Prosthetic head. Buccal, Mesial, Distal, Lingual.
- \* Use this measurement to order abutments and Impression copings.
- \* Choose locator abutment that is the height of your greatest depth
- \* Replace healing abutments.
- \* Take impression for custom tray (two days in Lab.)

### Second Appointment:

- \* Remove healing abutment.
- \* Place Locator abutments using a locator tool.
- \* Take impression. Using Locator impression copings
- \* Replace healing abutments, Pay special attention to abutment location if abutments are differing lengths.
- \* Send impression and all retentive males to Laboratory. Rx requesting Base plate and Wax Rims (two days in Lab.)

### Third Appointment:

- \* Take Bite registration and return for Set-up. (three days in Lab.)

### Fourth Appointment:

- \* Try-in wax-up and verify bite.
- \* Return for proses. (two days in Lab.)

### Fifth Appointment:

- \* Insert Denture. Torque locator abutments to 30Ncm.
- \* Denture will be returned with a 3.0 lb. Pink retentive male. Unless specified. The clear 5.0 lb. and the blue 1.5 lb. Are also included.