



Locator flow chart: Retrofit Current Denture

First Appointment:

- * Remove healing abutment – Measure depth of tissue, From the top of the Prosthetic head. Buccal, Mesial, Distal, Lingual.
- * Use this measurement to order abutments and attachments.
- * Replace healing abutments. (two days in Lab.)

Second Appointment:

- * Remove healing abutment.
- * Place Locator abutments. Using a locator tool, Torque to 30Ncm.
- * Relieve inside of denture to accommodate abutments.
- * Take reline impression. Through entire denture base. Using the metal housing and black insert.
- * Use of an impression coping not recommended.
- * If replacing healing abutments, Pay special attention to abutment location if abutments are differing lengths.
- * Send impression with housings and all retentive males to Laboratory. (one day in Lab.)

Third Appointment:

- * Reline will be returned with a 3.0 lb. Pink retentive male. Unless specified. The clear 5.0 lb. and the blue 1.5 lb. Are also included.
- * Deliver Denture